






ROOF HATCHGUARD



ISOMETRIC VIEW



INSTALLATION STEPS:

- 1. Lower hatch guard over roof hatch (removal of clamp feet and bolts may be necessary).
- 2. Position guard so that the hatch door can open fully.
- 3. The gate should be on the exit side of the hatch.
- 4. Tighten both clamp bolt sides until clamp feet on both sides are contacting the roof hatch curb.
- 5. Tighten both clamp bolts of one side two full rotations.
- 6. Check bolt tension Bi-annually.



EDGE FALL PROTECTION, LLC
6294 BURRY DR. EDEN PRAIRE
MN 55346
TF/F: 844-314-1374
SALES@edgefallprotection.com

REVISION	DESCRIPTION	BY:	DATE:

PROJECT:

PRODUCT SUMMARY

www.edgefallprotection.com


TITLE:

Roof HatchGuard

sales@edgefallprotection.com

SIZE: A3	DWG NO:	REV: 00
DATE:	DRAWN:	CHECKED:
SCALE: AS SHOWN	WIEGHT:	SHEET 1 OF 2

ROOF HATCHGUARD



EDGE FALL PROTECTION, LLC
6294 BURRY DR. EDEN PRAIRE
MN 55346
TF/F: 844-314-1374
SALES@edgefallprotection.com

REVISION	DESCRIPTION	BY:	DATE:

PROJECT:
PRODUCT SUMMARY
www.edgefallprotection.com

TITLE:
Roof HatchGuard
sales@edgefallprotection.com

SIZE: A3	DWG NO:	REV: 00
DATE:	DRAWN:	CHECKED:
SCALE: AS SHOWN	WEIGHT:	SHEET 2 OF 2